




# Numeric *128* and Roman *VIII*

**Component Identification**



\*The above illustrations in this instruction manual may be differ from the actual appearance of your watch.

QUARTZ			
<i>Local Time Zone</i>	<i>Time Indication</i>	<i>Hour hand</i>	<i>Center hour hand</i>
		<i>Minute hand</i>	<i>Center minute hand</i>
		<i>Second hand</i>	<i>Center second hand</i>
	<i>Time Setting</i> <i>(by turning Crown)</i>	<i>Crown at:</i>	
		<i>1<sup>st</sup> click</i>	<i>Time setting</i>
<i>Dual Time Zone</i>	<i>Time Indication</i>	<i>Hour hand</i>	<i>24-hour subdial hand</i>
		<i>Minute hand</i>	<i>60 minutes subdial hand</i>
	<i>Time Setting</i> <i>(by pushing Button A / B)</i>	<i>Crown at:</i>	
		<i>Normal position</i>	<i>Button A : -1 hour / push</i> <i>Button B : +1 hour / push</i>
		<i>1<sup>ST</sup> click</i>	<i>Button A : -1 minute / push</i> <i>Button B : +1 minute / push</i>

### Adjustment on Dual Time Hands Position

- \* After setting or replacement of the battery, before setting the time, check if the dual time hour hand and dual time minute hand are at the "0" (12 o'clock) position.
- \* If either the dual time hour hand or the dual time minute hand is not at the "0" position, reset it/them following the procedure shown below:
  1. Pull out the Crown to first click
  2. Keep both Buttons A and B pressed at the same time for more than 2 seconds, then release the Buttons.
    - \* Dual time hands move and return to where they were.
  3. Press Button A or B to reset the dual time hands to "0" position.
    - \*Button A: dual time hour hand moves clockwise.
    - \*Button B: dual time minute hand moves clockwise.
    - \*The dual time hands move quickly if the respective Buttons A and B are kept pressed.
  4. Push the Crown back in the normal position.

### Local Time Setting

1. Pull out (unlock) the Crown to first click when the Second hand is at the 12 o'clock position.
2. Rotate the Crown to set the Hour and Minute hands (make sure AM/PM is set correctly).
3. Push (lock) the Crown back in the normal position in accordance with a time signal.

## Dual Time Setting

\* When moving to a country or area in a different time zone, adjust the dual time hands to that country / area:

### QUICK SET OF THE DUAL TIME HOUR HAND

1. Crown at normal position.
2. Adjust the time by pressing the Button A or B.
  - Button A: - 1 hour / push
  - Button B: +1 hour / push

### PRECISE ADJUSTMENT OF THE DUAL TIME MINUTE HAND

1. Pull out (unlock) the Crown to first click when the Second hand is at the 12 o'clock position.
2. Adjust the time by pressing the Button A or B.
  - Button A: -1 minute / push
  - Button B: +1 minute / push
3. Push (lock) the Crown back in the normal position in accordance with a time signal.